

Rev1.0 28.11.02 JMA / Page:1



- Select 3 Com US Robotics modem (compatible with TD-33) as shown on the following display.
- Confirm with OK in order to close the two windows.
- The controller is now configured.
- Connect the modem with the controller.

	Tel: 262-446-0000
WESTERMO	Fax 262-446-0300
	E-mail: bob@grossautomation.com
Configuring the Millenium II C Logic Softw	Controller with the Crouzet vare M2.
Choire de la commande de configuration Nom du modèle Commande de configuration Arte log 158 152005+0(64)06 Pt 55050-2515 OK Annuler Poir de modèle ELSA Menduler 5 Arte log 158 152005+004 062105Pt 55050-2515-4 Arte log 158 152005+004 062105Pt 55050-2515-4 Chill S Robot	

• Select Controller again and set up in order to define PC modem settings.



Rev1.0 28.11.02 JMA / Page:3

Westermo	Tel: 262-446-0000 Fax 262-446-0300 E-mail: bob@grossautomation.com	
Configuring the Millenium II Controller with the Crouzet Logic Software M2.		
Image: Second lear en unitial of formal intervention of the second lear en unitial of formal intervention of the second lear en unitial of formal intervention of the second lear en unitial of formal intervention of the second lear en unitial of	Present Technologies Soft Holden AMI Edvana Exercise Perminent to prevalue En to prevalue Para Para	

• Click on the setting button to open the window above to the right.

Diffuente contrôle d'egeux Diffuence por secorrecter Diffuence in correcte Diffuence in correcte Diffuence in correcte Diffuence in correcte	Origen le contrôle de flux
lizezenostrini I	<u>-</u>
Earaniètes supplémentaires	

- Click the advanced button.
- Check no flow control and no error correcting control.
- Confirm with Ok.

- the configuration is now completed
- Select:Controller→connection→connect in order to establish the connection.

Rev1.0 28.11.02 JMA / Page:4



- Windows 98 SE
- Westermo telephone modem TD-33 V.34 or V.90
- PCMCIA modem on PC side